
CRANACH®

INSTALLATION MANUAL

Bathtub Faucet



ENGLISH

SAFETY NOTES

- MARNING: To prevent product failure, property damage, and personal injury, please follow these guidelines:
- The shower is designed exclusively for bathing, personal hygiene, and body cleaning purposes.
- ↑ The shower arm is intended solely to support the showerhead. Do not hang any additional items from the shower arm.
- A Regularly clean your CRANACH product as needed to prevent the buildup of mineral scale and/or soap residue.
- ⚠ Please refer to the Cleaning Recommendations when choosing a cleaning agent for this product. Avoid using cleaning products that contain chlorine bleach, lye, hydrochloric acid, formic acid, acetic acid, or abrasive materials.
- A FAILURE TO ADHERE TO THESE INSTRUCTIONS MAY LEAD TO PRODUCT DAMAGE, MALFUNCTION, AND VOIDING OF THE WARRANTY.

INSTALLATION CONSIDERATIONS

CRANACH recommended that this unit be installed by a licensed professional plumber.

Before starting the installation, please read these instructions carefully and make sure you have all the required tools and materials on hand

To avoid the risk of scalding, ensure that the maximum output temperature of the shower mixing valve (not included) does not exceed 120°F (49°C).

Keep this booklet and the receipt (or other proof of date and place of purchase) for this product in a safe place. The receipt is required should it be necessary to request warranty parts.

We're Here to Help!

Visit our Support Center for detailed product guides, warranty policies, and troubleshooting tips. Need instant assistance? Reach out via live chat or email us directly at support@cranachhome.com. For your convenience, we've provided quick access through the following QR codes:

Warranty Services

Scan the QR code below to quickly register your product warranty or access warranty-related information, ensuring peace of mind while using our products.



cranachhome.com/warrantv/


TOOLS REQUIRED




PARTS IN THE BOX

Read over these instructions thoroughly before beginning installation. Make sure that you have all tools and supplies needed to complete the installation.


C02.BA11




INSTALLATION




After wrapping the tape, connect the curved angle connector to the water outlet connector. (The distance between the hot water outlet and cold water outlet connector is 5 7/8", the height apart from floor should be fixed according to the bathtub height.)



Screw the decoration cover onto the curved angle connector Then install themixer's body to the curved angle connector via the two connecting nuts, and fix them by spanner.(Note: wrapping some tapes on the spanneris suggested to avoid scratching the product surface).




Then mount the shower hose to the mixer and hand shower.



The above installation instruction is also applicable to the shower mixer's installation.

INSTALLATION



- 1. Open water valve to check if there is any leakage.
- 2. When turning the handle upward, the valve is open. And the turning angle can control water outflow. The user can turn it to the left or right to right to regulate the water temperature.
- 3. Normally water will go out from the spout firstly by default. And the user can switch it to the hand shower by puling the switch valve(as right illustration). This switch can reset automatically after closing water.

WARRANTY

Parts and Finish:

All parts (excluding electronic parts and batteries) and finishes of CRANACH products purchased from authorized CRANACH sellers are warranted to the original consumer purchaser to be free from defects in material and workmanship for as long as the original consumer purchaser owns the home in which the faucet(s) are installed.

For commercial purchasers or multi-family residential properties (such as apartments and condominiums), the warranty period is 10 years from the date the product is received by the original purchaser or their authorized representative (e.g., installation contractor).

Electronic Parts:

Electronic parts (excluding batteries), if applicable, that are part of CRANACH products purchased from cranachhome.com or authorized CRANACH sellers are warranted to the original consumer purchaser to be free from defects in material and workmanship for 5 years from the date the product is received for residential use, 1 year for commercial purchasers. Batteries are not covered under this warranty.

What We Will Do:

If a defect is found during the applicable warranty period, CRANACH will provide replacement parts free of charge. This includes any part or finish that proves defective in material or workmanship under normal installation, use, and service. Before returning your faucet to CRANACH, please visit our website or contact our customer service team (via phone or email) for troubleshooting assistance


Exclusions & Limitations:

This warranty does not cover damage caused by abuse, misuse, or improper care, lack of maintenance or improper installation, freezing water or excessive water pressure, abrasive cleaning products, or use in violation of applicable codes or regulations. Labor charges incurred during installation, repair, or replacement, damage incurred during installation or removal, or incidental or consequential damages, are excluded.

CARE AND CLEANING

Gently clean the product with clear water and wipe dry using a soft, lint-free cloth. Do not use soaps, acid, polish, abrasives or rough materials that may damage the surface.

SPECIFICATION



8

CRANACH®

CR_INSTALLATION_V1.0_202501

7933 Ley Rd Houston, TX, 77028 24hours Hotline: + (1) 888-263-8999

Email: info@cranachhome.com